

FAA APPROVED
A I R P L A N E F L I G H T M A N U A L

MAULE AIRCRAFT CORPORATION

JACKSON, MICHIGAN

MODEL M-4-220 SERIES

(INCLUDES MODELS M-4-220, M-4-220S,
M-4-220C, M-4-220T)

AIRPLANE SERIAL NO. _____

FAA IDENT. NUMBER _____

(THIS DOCUMENT MUST BE KEPT IN THE AIRPLANE AT ALL TIMES)

APPROVED: John W. Husley
for JOHN A. CARRAN, CHIEF
Engineering & Manufacturing Branch
Central Region

DATE: September 28, 1966

MAULE MODEL M-4-220 SERIES

AIRPLANE FLIGHT MANUAL

LOG OF REVISIONS

Rev. No.	Page Number(s)	Description	Date of Revision	Approved by
1	2,3, & 4	Maximum take off weight increased to 2300 pounds and Center of Gravity Limits changed	7/7/67	Original signed by J. W. Hurley, for Chief, Engineering and Manufacturing Br. Central Region
2	1	Add optional prop	9/12/69	Original signed by H. E. Mannick Supervisor ATL EMDO
3	1	Add McCauley 2A34C22 propeller	9/24/70	Original signed by John F. Vogel Chief, Engineering and Manufacturing Br. Southern Region
4	3	Revised "Type of Operation Authorized" placard and rearranged sections L and M, deleting the letter "M"	11/27/72	<i>John F. Vogel</i> Chief, Engineering and Manufacturing Branch Southern Region, FAA 27 NOV 1972
5	3, 4, 5	Added " <u>PREFLIGHT INSPECTION</u> " to II PROCEDURES.		<i>John R. James</i> Manager, Atlanta Aircraft Certification Office FAA, Central Region Date: <u>May 1, 1984</u>

FAA APPROVED
Date: 7/7/67

Page i

MAULE AIRCRAFT CORPORATION

AIRPLANE FLIGHT MANUAL

MAULE M-4-220C/S

LOG OF SUPPLEMENTS

SUPP. NO.	NO. OF PAGES	DESCRIPTION	APPROVAL DATE
1	1	Installation of EDO Model 248A2440 or 248B2440 Floats - Maule STC SA610CE (Drawing 9047A, Rev. B & DCN M3902). Revised	11/29/68 09/19/69
2	2	Installation of Federal Model C2200H Retractable Skis .	11/29/68
3	1	Maximum Continuous Full Throttle Operation.	05/14/73
4	2 3	Operation of aircraft with Wing Tip Auxiliary Fuel Tanks installed. Revised	10/31/73 09/12/74
5	2	Flight operation with Right Rear Passenger Door removed .	05/12/83
6	2	Installation of Federal Model A2000A Wheel Replacement Skis .	01/25/84
7	3	Installation of Fleet Model 2500 Floats . *	06/16/86
8	5	Installation of Fli-Lite 3000 MK IIIA Skis - Maule Drawing 9079A .	01/07/87
9	3	Operation of aircraft when existing Wing Assemblies, Ailerons, Flaps and Flap Ratchet are replaced with M-5 Wing Assemblies 2110X-L/R or 2110X-30, Ailerons, Flaps and 20°/40° Flap Ratchet in accordance with Maule Modification Kit No. 10 .	10/17/97
-	5	Installation of Apollo MX20 Multi-Function Display - Maule Drawing 7265A .	08/15/02
-	8	Installation of GARMIN GNC-420 (GPS/COMM) System - Maule Drawing 7251A .	06/30/03
-	9	Installation of GARMIN GNS-530 (GPS/NAV/COMM) System - Maule Drawing 7253A .	06/30/03
-	4	Installation of GARMIN GTX-330 Mode S Transponder Traffic Information System (TIS) - Maule Drawing 7255A .	06/30/03
10	2	Flight operation with either one (not both) of the Front Doors removed .	09/02/03

MAULE MODEL M-4-220 SERIES

AIRPLANE FLIGHT MANUAL

TABLE OF CONTENTS

SECTION I - LIMITATIONS

Engine Page 1
Engine Limits. Page 1
Fuel Page 1
Propeller. Page 1
Power Plant Instruments. Page 1
Airspeed Limits. Page 2
Maneuvers. Page 2
Flight Load Factors. Page 2
Maximum Weight Page 2
Center of Gravity Limits Page 2
Placards Page 3
Fuel System Operation. Page 3

SECTION II - PROCEDURES

Normal Procedures. Page 3
Emergency Procedures Page 4

FAA APPROVED
DATE: 9/28/66

MULE MODEL M-4-220 SERIES

AIRPLANE FLIGHT MANUAL

I. LIMITATIONS

The following limitations must be observed in the operation of this airplane:

- | | |
|-----------------------------|---|
| A. Engine | Franklin 6A-350-C1 |
| B. Engine Limits | Take Off (5 Min) 2800 RPM & F.T.
(220 HP). METO POWER 2800 RPM @
26.5 Hg (194 HP) |
| C. Fuel | 100-130 Minimum Grade
Aviation Gasoline |
| D. Propellers | McCauley 2A31C21/84S-8
McCauley 2A31C21/84S-6
McCauley 2A34C22-N/S84SF-6
McCauley 2A34C22-N/S84SF-8 |
| E. Power Plant Instruments: | |
| Cylinder Head Temp | Green Arc: 200-390° F.
(Normal Operating Range)
Red Radial: 390° F. |
| Manifold Pressure | Green Arc: 14.5-26.5 In. Hg.
(Normal Operating Range)
Yellow Arc: (Caution) 26.5-29.0 Hg.
Red Radial: 29.0 In. Hg. |
| Oil Temperature | Green Arc: 100-235° F.
(Normal Operating Range)
Red Radial: 235° F. |
| Oil Pressure | Green Arc: 55-80 psi
(Normal Operating Range)
Yellow Arc: (Caution) 0-55 psi
Red Radials: 80 psi |
| Tachometer | Green Arc: 1800-2800 RPM
(Normal Operating Range)
Red Radial: 2800 RPM |
| Fuel Pressure | Green Arc: .5-9 psi
Red Radials: .5 and 9 psi |

FAA APPROVED

DATE: 9/28/66

REVISED: 9/24/70

REVISED:

MAULE MODEL M-4-220 SERIES
AIRPLANE FLIGHT MANUAL

F. Airspeed Limits: (Calibrated Airspeed)

Never Exceed (V_{ne})	180 mph (156K)	(Red Radial)
Caution Range	145-180 mph (126-156K)	(Yellow Arc)
Design Cruising Speed (V_C)	145 mph (126K)	
Normal Operating Range	62-145 mph (54-126K)	(Green Arc)
Max. Design Maneuvering Speed (V_p)	125 mph (109K)	
Max. Flap Extension Speed (V_f)	90 mph (82K)	
Flap Operating Range	56-90 mph (49-82K)	(White Arc)

NOTE: Airspeed Instrument Markings and their Significance:

1. Radial RED line marks the never exceed speed, which is the maximum safe airspeed.
2. YELLOW Arc on indicator denotes range of speeds in which operations should be conducted with caution and only in smooth air.
3. GREEN Arc denotes normal operating speed range.
4. WHITE Arc denotes speed range in which flaps may be safely lowered.

G. Maneuvers: Normal Category maneuvers only are approved.

H. Flight Load Factors: (At maximum gross weight of 2300 lbs.)

Maneuver: Positive - 3.8g
 Negative - 1.5g
 Flaps Extended - 1.9g

WARNING: Use controls with caution above 125 mph (109K) CAS.

I. Maximum Weight - 2300 lbs.

J Center of Gravity Limits: (+15.6) to (+19.0) at 2300 lbs.
 (+14.5) to (+20.5) at 2100 lbs.
 (+11.1) to (+20.5) at 1500 lbs. or less

Straight line variation between points
 given. Datum: Wing Leading Edge

NOTE: It is the responsibility of the airplane owner and the pilot to insure that the airplane is properly loaded. See loading instructions provided in the Weight and Balance Section of the Airplane Flight Manual.

FAA APPROVED
 DATE: 9/28/66
 Revised 7/7/67

MAULE MODEL M-4-220 SERIES

AIRPLANE FLIGHT MANUAL

K. Placards:

"THIS AIRPLANE MUST BE OPERATED AS A NORMAL CATEGORY AIRPLANE IN COMPLIANCE WITH THE OPERATION LIMITATIONS STATED IN THE FORM OF PLACARDS, MARKINGS AND MANUAL."

"NO ACROBATIC MANEUVERS INCLUDING SPINS APPROVED."

"ROUGH AIR OR MANEUVERING SPEED: 125 MPH (109K)"

"TAKE OFF WITH 15° FLAPS"

"SEE LOADING INSTRUCTIONS IN WEIGHT AND BALANCE SECTION OF AIRPLANE FLIGHT MANUAL."

Type of Operation Authorized:

"THIS AIRPLANE APPROVED FOR DAY OR NIGHT IFR NON-ICING FLIGHT WHEN EQUIPPED IN ACCORDANCE WITH FAR 91 OR FAR 135"

Fuel System Operation:

"FUEL REMAINING IN TANK WHEN INDICATOR READS ZERO CANNOT BE USED SAFELY IN FLIGHT."

L. Caution:

Take off and land on fullest main tank

Flight into icing conditions not approved

II. PROCEDURES

PREFLIGHT INSPECTION:

A. INTERIOR:

1. BAT. Switch.....ON
2. Fuel gauges.....CHECK INDICATIONS
3. All Electrical Switches.....OFF
4. BAT. Switch.....OFF
5. Flaps.....FULL DOWN

- B. EXTERIOR: Begin at the left front door, proceed around the left wing to the nose area, then around the right wing and back to the fuselage, then around the tail section.

1. Fuel drains behind step.....DRAIN (2)
2. Left Flap.....CHECK HINGES & CONTROL ATTACHMENT
3. Aileron.....CHECK HINGES & CONTROL ATTACHMENT
4. Wing Top.....CHECK FOR WRINKLES AS INDICATION OF INTERNAL DAMAGE

FAA APPROVED

DATE: 9/28/66

Revised 7/7/67

REV. 5 dated: 5/1/84

MAULE MODEL M-4-220 SERIES
AIRPLANE FLIGHT MANUAL

II PROCEDURES: (Cont'd)

5. Wing Main & Aux Fuel Tank Drains.....DRAIN (2)
6. Wing tip and nav. light.....CHECK FOR DAMAGE
7. Auxiliary fuel tank.....VISUALLY CHECK QUANTITY
8. Landing light.....CHECK FOR DAMAGE
9. Wing Tiedown.....REMOVE
10. Pitot tube.....REMOVE COVER
11. Stall Warning Switch.....CHECK FOR FREEDOM OF MOVEMENT
12. Main Fuel Tank.....VISUALLY CHECK QUANTITY
13. Left Landing Gear.....CHECK TIRE INFLATION AND BRAKE LINE SECURITY
14. Bottom left side of cowl.....DRAIN GASCOLATOR (1)
15. Top Cowl; Oil access door.....CHECK OIL QUANTITY
16. Propeller.....CHECK LEADING EDGE FOR DAMAGE
17. Air inlets.....CHECK FOR FOREIGN OBJECTS, INSPECT VISIBLE CONNECTIONS AND COMPONENTS
18. Right landing gear.....CHECK TIRE INFLATION AND BRAKE LINE SECURITY
19. Right wing and controls.....INSPECT SAME AS LEFT WING
20. Wing Main & Aux Fuel Tank Drains.....DRAIN (2)
21. Right fuselage side and top.....INSPECT FOR WRINKLES AS INDICATION OF INTERNAL DAMAGE
22. Static port.....CLEAR
23. Right Stabilizer.....CHECK ATTACHMENT POINTS AND STRUT
24. Right Elevator.....CHECK HINGE POINTS
25. Rudder.....CHECK HINGE POINTS, CONTROL ATTACHMENTS AND NAV. LIGHT
26. Tailwheel.....CHECK INFLATION, ATTACHMENTS, REMOVE TIEDOWNS
27. Left Elevator.....CHECK TAB CONTROLS AND ALL HINGE POINTS
28. Left Stabilizer.....CHECK ATTACHMENT AND STRUT
29. Left Fuselage side and bottom.....CHECK FOR WRINKLES AS INDICATION OF INTERNAL DAMAGE
30. Left side Static port.....CLEAR

NORMAL FLIGHT OPERATIONS:

A. Normal Procedures

1. Wing Flap Settings:

Takeoff	15°	(First Notch)
Cruise	0°	(Full Up-Retracted)
Landing	35°	(Second Notch)

2. Best Rate of Climb Speed: 90 MPH (CAS) at sea level

FAA APPROVED

DATE: 9/28/66

Revised 7/7/67

REV. 5. dated: 5/1/84

MAULE MODEL M-4-220 SERIES

AIRPLANE FLIGHT MANUAL

II PROCEDURES: (Cont'd)

3. Right Rudder Trim: Use of right rudder trim is recommended during takeoff and climb and high speed level flight to reduce the amount of right rudder force required. During level flight at moderate speeds and glide, the trim control should be in the OFF position.
4. Stall Warning Indicator: The electric stall warning system will light a red light on the instrument panel at approximately seven mph above the stalling speed. It will be inoperative when the master switch is off.
5. Loss of altitude prior to recovery from a stall may be as much as **200** feet.
6. Maximum 90° crosswind velocity demonstrated: 20 mph
7. Anti-Collision Beacon
WARNING: Anti-collision light may cause adverse effect on pilot when flying in overcast or haze. Recommend it be turned off under these conditions.

B. Emergency Procedures:

1. Air Restart
Check mixture rich
Use Aux. pump for engine restart.
2. Engine Failure
Use 15° flap setting (first notch), maintain 85 mph. (78K) CAS. If air restart is not possible, cut ignition and master switches. Execute forced landing.
3. Engine Fire
Turn fuel valve OFF.
Open throttle to full ON position.
Turn ignition switch OFF.

FAA APPROVED

DATE: 9/28/66

REV. 5 dated: 5/1/84